



6 LOBE WEDGE BIT GAGE



April 1, 2005

This gage is for determining the acceptability of the wedging characteristic of 6 Lobe recess wedge driver bits.

Gaging Procedure:

1. Measure the length of the chamfer on the point end of the bit.



Greenslade & Company, Inc. USA

817-870-8888 817-870-9199 Fax

E-mail: greensladeandcompany@sbcglobal.net

2. Turn the indicator ON. Press the face of the gage on to a flat surface and press the "Origin" button until the display reads all zeros.



Greenslade & Company, Inc. USA
817-870-8888 817-870-9199 Fax
E-mail: greensladeandcompany@sbcglobal.net

3. Insert the wedge bit into the gage until the bit stops. Record the indicated value.



Greenslade & Company, Inc. USA
817-870-8888 817-870-9199 Fax
E-mail: greensladeandcompany@sbcglobal.net

4. The wedge bit is acceptable if the displayed length on the indicator, minus the chamfer length, is within the values listed below:

Recess Size	Max. Wedge Length	Min. Wedge Length
T-25W	.060	.050
T-30W	.075	.065

Greenslade & Company, Inc. USA

817-870-8888 817-870-9199 Fax

E-mail: greensladeandcompany@sbcglobal.net